

HOW TO INSTALL THE DRIFT BUTTON



All you need is a flathead screwdriver; it should only take a minute to install.

1. Remove handbrake cover, (slide/twist it forward)
2. Using a flathead screwdriver flip the tabs on each side of the handbrake out in order to drop the spring (the standard handbrake button will sink in and stay)
3. Slide the handbrake cover back on
4. Push the drift button onto the standard one

When the drift button is pushed in it will leave the handbrake inactivated even when pulled up, when the drift button is pulled out the handbrake will lock when pulled up.