

FC35 RX7

Sunroof Installation

Congratulations on purchasing your Sunroof! This leaflet contains important information regarding your product.

Kit Contents:

- 1 x Sunroof
- 6 x M5 10mm Bolts
- 6 x Spring Washers
- 1 x Rubber seal
- 1 x Auto Silicone
- 2 x Rubber Gloves

Please follow these directions:

1. Carefully remove interior sunroof lining panel as you will re-fit this
2. Undo the six nuts holding the sunroof to the tracks using a 10mm socket
3. Remove the sunroof
Note: At this point it is advised to check and lubricate the tracks
4. Drill the 8 holes (as pictured below) in your new sunroof for the roof lining clips using the old sunroof holes as a guide to drill size and re-use the plastic clips.

WARNING: Be very careful not to over drill into the sunroof panel



5. Test fit the lining before fitting sunroof to the car
6. Using the gloves and silicone supplied attach the rubber seal around the edge of the cars roof

Note: Allow silicone to completely dry before closing the sunroof

7. Using the 6 bolts and washers supplied fix the new sunroof to the tracks
8. Re-fit the roof lining